

Bois Chamois Vintage Hardwood Flooring

WAX FINISHING INSTRUCTIONS

INITIAL WAX APPLICATION

Initial waxing of the floor is completed on-site after successful installation of your hardwood floors.

STEP ONE: Vacuum the floor and clean any marks left by others. DO NOT SAND OR APPLY WATER TO THE FLOOR.

Apply our special Camelot paste wax directly to Bois Chamois flooring using a white cotton cloth. Let paste wax set for 20 minutes. Machine buff with a red pad, apply a second coat of wax and buff with a red pad. Let stand for 20 minutes and buff again with a white pad. For additional sheen, wax may be applied a second time within a month of first application.

STEP TWO: Clean the floor using Trip Trap Soap as needed after wax treatment. Dissolve soap (follow instructions on label) in a bucket of warm water and clean flooring using a **damp mop**. Use a second bucket of clean water to rinse the mop every time it is used while cleaning the floor. Change the rinse water frequently. Use as little water as possible and do not allow mixture to "pool" on floors. Avoid walking on floors until dry, a minimum of 2 hours.

MAINTAINING WAX FINISHES

Dust mop or vacuum the floor as needed. Clean the floor using Trip Trap Soap as traffic dictates. Reapply wax to traffic lanes or when floor begins to exhibit faded areas. Wax may need to be applied to the entire floor every several years depending on the amount of traffic and wear.